





## Card mod. SC0204





SW1, SW2: three positions rotary switches (1-0-2)

L1, L3: red LEDs L2, L4

green LEDs

relays energized when the relevant rotary switch (SW1 or SW2) is on K1, K2:

position 2

CN1: connector to link other cards of the SC family using the proper flat

cable

PWR: LED signalling the power on condition

BUS: terminal block for card programming and for the connection to the

4-wire bus

J1, J2, J3, J4: jumpers to set each LED as status (jumper not inserted ) or alarm (jumper

inserted)

On the top of the card, 2 white labels allow to write, by a permanent marker, the addresses (input and output) of the card.

The card handles the following points as inputs (in other words the status of these points can be acquired via bus):

SW1 position 1: input 1 (active when switch SW1 is on position 1) SW1 position 2: input 2 (active when switch SW1 is on position 2) SW2 position 1: input 3 (active when switch SW2 is on position 1) SW2 position 2: input 4 (active when switch SW2 is on position 2)

The position 0 of the switches does not affect any input points that may be handled via bus. The card handles the following points as *outputs* (in other words the status of these points can be forced via bus):

- L1: output 1 (when ON it forces the lighting of LED L1)
- L2: output 2 (when ON it forces the lighting of LED L2)
- L3: output 3 (when ON it forces the lighting of LED L3)
- L4: output 4 (when ON it forces the lighting of LED L4)

## Operation

The position of the switches SW1 and SW2 is available through the bus specifying the address of the input section of SC0204 card and the point number as above described. When the switches are set to position 2, the relevant relay (K1 or K2) will be energized: this feature may be useful for manual and local commands.

> Rel.: 1.2 March 2000 Page 1






The four LEDs must be switched on or off via bus, specifying the address of the output section of SC0204 card and the point number as above described. If the SC00AC alarm card in connected by the proper flat cable, the lighting of a LED having its related jumper inserted, causes the begin of the alarm sequence on SC00AC card itself (no alarm occurs if the relevant jumper is not inserted). In addition the connection of the alarm card allows the blinking of the LED set as alarm; the pressing of the acknowledge pushbutton on SC00AC, will cause the change of all LED activated in that moment from blinking to constant lighting.

The lamp test function too is handled by SC00AC card (if connected through the proper flat cable).

The input and output addresses programming must be done through the proper FXPRO programmer.

## Card connection diagram



## Electrical characteristics

Rel.: 1.2 March 2000 - Page 2